


EXPLODED VIEW OF CDCF10 CS4



PARTS LIST OF CDCF10 CS4

| ITEM# | PARTS NUMBER | PARTS DESCRIPTION | ITEM# | PARTS NUMBER | PARTS DESCRIPTION |
|-------|----------------|---------------------------|-------|--------------------|-----------------------|
| 1 | B10177-101 | Drag Knob Assembly | 36 | 300250-001 | Rotor |
| 2 | B06177-101 | Spool Assembly | 37 | 305236-001 | Trip Bar |
| 3 | 405003-101 | Washer Retaining Clip | 38 | 320208-001 | Balance Block |
| 4 | 611029-001 | Ear Washer | 39 | 310078-001 | Spring |
| 5 | 612041-001 | Keyed Washer | 40 | 303012-001 | Pivot Arm |
| 6 | 903031-003 | Washer(2req.) | 41 | 304244-001 | Bail Arm Cover |
| 7 | 409013-001 | Spool Clicker Spacer Ring | 42 | 905119-001 | Screw |
| 8 | 406032-001 | Spool Click Plate | 43 | 903057-004 | Rotor Washer |
| 9 | 905254-003 | Screw | 44 | 905135-003 | Screw(3req.) |
| 10 | 407018-001 | Spring | 45 | 105080-001 | Ball Bearing Retainer |
| 11 | 905231-003 | Screw(2req.) | 46 | 906037-007 | Bearing(2req.) |
| 12 | 400724-007 | Spool | 47 | 109816-001 | Bearing Holder |
| 13 | 402029-101 | Line Clip | 48 | 107026-001 | Clutch Spring |
| 14 | 407074-001 | Spring | 49 | 110001-001 | Clutch Assembly |
| 15 | 903324-001-002 | Spool Adjust Washer | 50 | 702186-005 | Pinion |
| 16 | 903241-001 | Main Shaft Washer(2req.) | 51 | 703034-201 | Bushing |
| 17 | 906036-001 | Bearing | 52 | 905087-001 | Screw |
| 18 | 712001-001 | Spool Holder | 53 | 703005-001 | POM Bushing |
| 19 | 719041-001 | Click Gear | 54 | 801029-001 | Clutch Switch Spring |
| 20 | 718282-002 | Main Shaft | 55 | 800078-001 | Clutch Switch |
| 21 | 905302-001 | Screw | 56 | B01177-101 | Body Assembly |
| 22 | 318001-001 | Rotor Nut | 57 | 513071-001 | Dust Cap |
| 23 | 319018-001 | Rotor Set Plate | 58 | 906008-001 | Bearing(2req.) |
| 24 | 903365-001 | Washer | 59 | 726063-002 | Oscillation Guide |
| 25 | 905120-003 | Line Roller Screw | 60 | 708140-001 | Oscillation Slider |
| 26 | 301078-001 | Bail Arm | 61 | 905165-003 | Screw |
| 27 | 317066-001 | Line Roller Collar | 62 | 103381-001 | Body Rear Cover |
| 28 | 109806-002 | Ball Bearing Bushing | 63 | 705196-002 | Oscillation Gear |
| 29 | 703004-101 | Sleeve | 64 | 700122-001 | Driver Gear |
| 30 | 315064-001 | Line Roller | 65 | 903057-002-003-006 | Washer |
| 31 | 906006-001 | Bearing(2req.) | 66 | B02177-101 | Body Cover Assembly |
| 32 | B05177-101 | Bail Assembly | 67 | 905314-001 | Screw |
| 33 | 317030-001 | Bushing(2req.) | 68 | 905296-001 | Screw(3req.) |
| 34 | 905294-001 | Bail Arm Screw(2req.) | 69 | B08177-101 | Handle Assembly |
| 35 | 307099-001 | Bail Holder | | | |