

CB6-L66/L73 Partslist

ITEM	P/N	DESCRIPTION	REMARK	ITEM	P/N	DESCRIPTION	REMARK
1	512003-101	Handle Cap		48	626002-001	Click Spring	
2	905134-003	Screw		49	905330-001	Screw	
3	906002-001	Handle Bearing		50	906031-012	Bearing(Spool Shaft)	
4	509124-001	Handle Knob		51	709033-001	Clip Ring	
5	510188-004	Handle Rivet		52	400770-001	Spool	
6	500259-002	Handle		53	310089-001	Click Spring	
7	903388-001	Handle Washer		54	711003-001	Magnet Control Dial	
8	709036-001	Clip Ring		55	906045-012	Bearing	
9	607073-001	Click Base		56	124024-001	Spool Cover	
10	625008-101	Click Shaft		57	415035-001	Spool Shaft	
11	502015-001	Star Drag		58	903392-001	Tension Wsher	
12	504071-001	Star Drag Bushing		59	631003-001	Magnet Plate	
13	906012-002	Crank Shaft Bearing		60	415027-001	Spool Shaft Pin	
14	201098-001	Gear Box Cover		61	419034-001	Magnet Holder	
15	200272-001	Gear Side Cover		62	334002-001	Magnet	
16	110024-001	One Way Clutch		63	905321-001	Screw	
17	114015-001	Sleeve		64	100278-001	Frame	
18	905323-001	Screw		65	101144-001	Thumb Rest	
19	923062-001	Drag Washser		66	814073-001	Spool release button	
20	700149-009	Drive Gear	CB6-L66	67	905116-001	Screw	
	700149-010		CB6-L73	68	905057-001	Screw	
21	705200-001	Trip Ratchet		69	815018-001	Release Slider	
22	704041-002	Crank Shaft		70	310088-001	Yoke Spring	
23	105075-001	Retainer		71	401012-001	Collar	
24	900003-001	E Ring		72	813049-001	Kick Lever Spring	
25	725037-001	Bushing		73	813050-001	Release Slider Spring	
26	815019-001	Kick Lever		74	702213-003	Pinion Gear	CB6-L66
27	905315-001	Screw			702213-004		CB6-L73
28	101145-001	Hood		75	705203-001	O/S Drive Gear	
29	814049-001	Worm Shaft Pin		76	903391-001	Washer	
30	727057-001	Worm Shaft		77	903387-004	Drag Disc	
31	705204-001	O/S Pinion Gear		78	628032-101	"O" Ring	
32	903417-001	Washer		79	903386-002	Washer	
33	722029-001	Line Guide Carrier		80	905063-101	Screw	
34	722027-001	Line Guide Carrier Nut		81	905331-001	Screw	
35	903201-002	Washer		82	903432-001	Washer	
36	715014-002	Line Guide Pawl		83	903431-001	Washer	
37	724009-001	Worm Shaft Guide		84	600228-001	Tension Knob	
38	704038-001	Worm Shaft Bush		85	903058-012	Washer	
39	900001-001	E Clip		86	903389-001	Spring Washer	
40	727046-001	Stabilizer Bar		87	310092-001	Star Drag Spring	
41	617086-001	Centrifugal Dial Ring		88	123012-001	Handle Arm Nut	
42	200271-001	Palm Side Cover		89	903420-001	Handle Nut Cap	
43	600220-001	Centrifugal Dial		90	520040-301	Insert Knob	
44	407057-001	Click Spring		91	905014-001	Screw	
45	628174-001	Dial Friction Ring		92	B08184-304	Handle Rivert Assy	
46	711002-001	Magnet Control Base		93	B06184-302	Spool Assy	
47	404028-001	Release button					

EXPLODED VIEW OF CB6-L66/L73

